## **Application**

## How do I install the Geotab NFC Key Reader?

A special harness called the IOX-NFC which contains the key reader for the NFC keys is required to be installed in the vehicle in order to use NFC driver keys. Below is a picture of the IOX-NFC and instructions on how to install it in your vehicle.

Unique solution ID: #1136 Author: n/a Last update: 2021-10-27 22:47

> Page 1 / 1 (c) 2024 Fleetistics <darryl.arnold@fleetistics.com> | 2024-05-18 20:39 URL: https://kb2.myfleetistics.com/index.php?action=faq&cat=8&id=137&artlang=en