

# Application

## Geotab Seatbelt Data


1 = unbuckled and vehicle is moving, 0 = buckled and moving, -1 = no seatbelt data during the times the vehicle was not moving.

The data may be easier to understand when viewed in a graph.

### Engine Data Profile 001 - EI - F-250(GO9)

● Driver seat belt (1 = unbuckled)

01/09/19 3:14:32 am - 01/09/19 12:18:34 pm



# Application

Author: n/a

Last update: 2021-05-06 21:09